

# GASTEC Instructions for No.113L Isopropyl Alcohol Detector Tube

## FOR SAFE OPERATION :

Carefully read this manual and the instruction manual of your Gastec Gas Sampling Pump.

### ⚠ WARNING :

1. Use only Gastec detector tubes in a Gastec pump.
2. Do not interchange or use non-Gastec parts or components in Gastec's detector tube and pump system.
3. Using non-Gastec parts or components in Gastec's detector tube and pump system or using a non-Gastec detector tube with a Gastec pump or using a Gastec detector tube with a non-Gastec pump may damage your detector tube and pump system, or may cause serious injuries, or death to the end-user. It will also void all warranties, and guarantees regarding performance and data accuracy.

### ⚠ CAUTION : If you do not observe the following precautions, you may suffer injuries or damage the product.

1. When breaking the tube ends, keep away from eyes.
2. Do not touch the broken glass tubes, broken pieces and reagent with bare hand(s).
3. The sampling time represents the time necessary to draw the air sample through the tube.  
The tube must be positioned in the desired sampling area for the entire sampling time or until the flow finish indicator indicates the end of the sampling.

### △ NOTES : For maintaining performance and reliability of the test results, observe the following.

1. Use Gastec Gas Sampling Pump together with Gastec Detector Tubes only for the purposes specified in the instruction manual of the detector tube.
2. Use this tube within the temperature range of 0 – 40°C (32 - 104°F).
3. Use this tube within the relative humidity range of 20 - 90%.
4. This tube may be interfered with by the coexisting gases. Please refer to the table "INTERFERENCES" below.
5. In less than 20% humidity atmosphere tubes will indicate lower reading.
6. The shelf life and storage condition of the tube are marked on the label of the tube box.

## APPLICATION OF THE TUBE :

Use this tube for detecting Isopropyl Alcohol in the air or in industrial areas and for determining the environmental atmospheric condition.

## SPECIFICATION :

(Because of Gastec's commitment to continued improvement, specifications are subject to change without notice.)

Measuring Range	20 – 50 ppm	50 – 800 ppm
Number of Pump Strokes	2	1
Stroke Correction Factor	0.4	1
Sampling Time	2 minutes per pump stroke	
Detecting Limit	15 ppm (n=2)	
Colour Change	Pink → Pale blue	
Reaction Principle	$\text{CH}_3\text{CH}(\text{OH})\text{CH}_3 + \text{Cr}^{6+} + \text{H}_2\text{SO}_4 \rightarrow \text{Cr}^{3+}$	

**Coefficient of Variance: 10% (for 50 to 200 ppm), 5% (for 200 to 800 ppm)**

**\*\*Shelf Life : Please refer to the validity date printed on the tube box.**

**\*\*Store the tubes in a dark and cool place.**

## CORRECTION FOR TEMPERATURE, HUMIDITY AND PRESSURE :

**Temperature :** Correct for temperature by the table below :

Tube Reading (ppm)	True concentration								
	0°C (32°F)	5°C (41°F)	10°C (50°F)	15°C (59°F)	20°C (68°F)	25°C (77°F)	30°C (86°F)	35°C (95°F)	40°C (104°F)
800	1850	1500	1150	950	800	750	720	690	650
600	1200	1000	820	700	600	550	540	510	480
400	650	590	520	450	400	380	360	340	320
200	260	250	250	220	200	190	180	170	160
100	–	–	–	50	100	95	90	85	80
50	–	–	–	–	50	45	40	40	40


**Humidity :** No correction is required.

**Pressure :** To correct for pressure, use the formula below.

$$\frac{\text{Tube Reading (ppm)} \times 1013 \text{ (hPa)}}{\text{Atmospheric Pressure (hPa)}}$$

## MEASUREMENT PROCEDURE :

1. For checking the leakage of the pump, insert a freshly sealed detector tube into pump.  
Follow instructions provided with the pump operating manual.
2. Break tips off a fresh detector tube with the tube tip breaker in the pump.
3. Insert the tube into the pump inlet with arrow (➔) on the tube pointing toward the pump.
4. Make certain the pump handle is all the way in. Align the guide marks on the pump body with the guide marks on the handle.
5. Pull the handle all the way out until it locks at one pump stroke (100 mL). Wait two minutes and confirm the completion of the sampling.
6. For smaller measurements less than 50 ppm, repeat the above sampling procedure one more time until the stain reaches the first calibration mark.
7. Read the concentration level at the interface where the stained reagent meets the unstained reagent.
8. If necessary, multiply the readings by the correction factors of temperature, pump strokes and atmospheric pressure.



## INTERFERENCES :

Substance	Concentration	Interference	Interference gas only
Alcohols		+	Pale blue
Acetone	≤ 1200 ppm	No	No discolouration up to 1200 ppm
Ethyl Acetate	≤ 450 ppm	No	No discolouration up to 450 ppm
Toluene	≤ 230 ppm	No	No discolouration up to 230 ppm
Benzene	≤ 75 ppm	No	No discolouration

This table of interference gases primarily expresses the interference of each coexisting gas in the concentration range, that is equivalent to the gas concentration. Therefore, the test result may show positive results due to other substances not listed in the table. If more information is needed, please contact us or our distributors in your territory.

## APPLICATION FOR OTHER SUBSTANCES :

Tube 113L can also be used for other substances as below :

Conversion Scale	
Propyl Alcohol Concentration (ppm)	130 160 215 330 440 560
Tube Reading (n=1) (ppm)	50 100 200 400 600 800

Conversion Scale	
Vinyl Trimethoxysilane Concentration (ppm)	6.5 10.0 15.0 20.0 25.0
Tube Reading (n=2) (ppm)	50 100 200 400 600 800

Conversion Scale	
Divinyl Methoxysilane Concentration (ppm)	6.5 10.0 15.0 20.0 25.0
Tube Reading (n=2) (ppm)	50 100 200 400 600 800

Conversion Scale	
Ethylene Glycol Monomethyl Ether Concentration (ppm)	75 190 300 420 530 650 760
Tube Reading (n=2) (ppm)	200 400 600 800

Conversion Scale	
Ethylene Glycol Monoethyl Ether Concentration (ppm)	110 260 410 560 700 850 1000
Tube Reading (n=2) (ppm)	200 400 600 800

Conversion Scale	
Ethylene Glycol Monobutyl Ether Concentration (ppm)	200 465 730 1000
Tube Reading (n=2) (ppm)	200 400

Conversion Scale	
Ethylene Glycol Monomethyl Ether Acetate Concentration (ppm)	300 370 500 760 1030 1300
Tube Reading (n=2) (ppm)	50 100 200 400 600 800

## CORRECTION FACTOR :

Detector tubes are primarily designed to measure specific gases. But it is also possible to measure other substances of similar chemical properties with the aid of a correction factor or chart. Therefore, please make use of the correction factor/chart measuring ranges as a reference. For more precise factor please contact your Gastec distributor.

## DANGEROUS AND HAZARDOUS PROPERTIES :

Threshold Limit Value-Time Weighted Average by ACGIH (2013): 200 ppm

Threshold Limit Value-Short Term Exposure Limit by ACGIH (2013): 400 ppm

## INSTRUCTIONS ON DISPOSAL :

The reagent of the tube uses a small amount of hexavalent chromium. When disposing the tube regardless of whether it has been used or not, follow the rules and regulations of your local government.

## WARRANTY :

If you have any questions regarding gas detection and the quality of the tubes, please feel free to contact your Gastec representatives.

Manufacturer : Gastec Corporation  
8-8-6 Fukayanaka, Ayase-City, Kanagawa 252-1195, Japan  
<http://www.gastec.co.jp/>  
Telephone +81-467-79-3910 Facsimile +81-467-79-3979

IM00113LE2  
Printed in Japan  
14E1Z